

MOOER

@Wah

Digital Auto Wah Pedal

Owner's Manual

Precautions

PLEASE READ CAREFULLY BEFORE PROCEEDING

Power Supply

Please connect the designated AC adapter to an AC outlet of the correct voltage. Please be sure to use only an AC adapter which supplies 9V DC, ⊕ ⊖ ⊖, center negative. Unplug the AC power adapter when not in use or during electrical storms.

Connections

Always turn off the power and all other equipment before connecting or disconnecting. This will help prevent malfunction and damage to any of the devices. Make sure to unplug all connection cables and power cords before moving this unit. To avoid deformation, discoloration, or other serious damage, do not expose this unit to the following conditions:

- *Direct sunlight
- *Heat sources
- *Magnetic fields
- *Extreme temperature or humidity
- *Excessively dusty or dirty location
- *High humidity or moisture
- *Strong vibration or shock

Interference with other electrical devices and Cleaning

Radios and televisions placed nearby may experience reception interference. Operate this unit at a suitable distance from radios and televisions. Clean only with a soft, dry cloth.

Handling

Do not apply excessive force to the switches or controls. Do not let paper, metal, or other objects into this unit. Take care not to drop the unit, and do not subject it to shock or excessive pressure.

FCC certification

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

Main Features

- 5 different Wah filter modes
- Two methods of operation : Auto (time based) and Touch (dynamic response)
- Versatile controls
- Full metal case

- Truebypass switching
- 9V power supply

Pedal layout



- 1. True bypass footswitch:** Engages and disengages the effect.
- 2. On/Off Led:** Shows the on/off status of the pedal. When the Led is lit the effect is engaged.
- 3. MODE control:** Selects the filter mode and simultaneously adjusts the MIX and ATTACK of the filter. The 5 filter modes are listed below:
LP (Low pass)
BP (bandpass)
HP (high pass)
SP (Standard)
TALK (vocals)
- 4. RANGE:** Adjusts the tonality of the filter
- 5. Operation method switch:** 'AUTO' is a time based filter. 'Touch' responds to the dynamics of the instrument.
- 6. SPEED / GAIN:** Adjusts the rate of the 'AUTO' wah or the input response of the 'TOUCH' wah.

- 7. DC in power jack:** Input for power supply ⊕ ⊖ ⊖, use a 9V DC regulated power supply.
- 8. Input jack :** 1/4" audio jack for connecting to the input device or instrument.
- 9. Output jack :** 1/4" audio jack, effect output for connection to amp or other devices.

Specification

Modes : 5 digital auto filters with 2 methods of operation.

Input : 1/4" mono audio jack. (Impedance: 470k Ohms)

Output : 1/4" mono audio jack (Impedance: 100 Ohms)

Power requirements: AC adapter 9V DC ⊕ ⊖ ⊖, center negative. Highly recommend to use Moer Micro Power.

Current Draw: 120mA

Dimensions : 93.5mm(D) x 42mm(W) x 52mm(H)

Weight : 140g

Accessories : Owner's Manual

**Notes : Any specification's update will not be amended in this manual.*

Owner's Manual

Precautions

お使いになる前にお読みください。

電源

Mooyer Microシリーズは、レギュレートされた⊕-⊖センターマイナスDC9Vアダプターを接続します。電池はご使用になれません。

接続

機器との接続や取り外しを行う際は、必ず電源をOFFにして行って下さい。電源を入れたままで接続や取り外しを行うと、機器が損傷する場合があります。移動や持ち運びを行う際は、本体から全てのプラグを外して下さい。変形や変色など、損傷を避けるため、下記の環境での使用はお控え下さい。

- 直射日光の当たる場所
- 磁場の強い場所
- 埃の多い場所や汚れのひどい環境
- 強い揺れやショック
- 放熱するものの近く
- 高温多湿な環境
- 湿度が高く、湿気の多い場所

他の電子機器による干渉、およびクリーニング時のご注意

ラジオやテレビなどの近くで本機を使用すると、電波による干渉を受けることがあります。ご使用の際はラジオやテレビなど、電波を発したり受信する機器の近くで使用しないで下さい。また、クリーニングの際は柔らかい乾いた布を使用して拭き取って下さい。

持ち運び、ご使用の際のご注意


スイッチやコントロールノブに無理な力を加えないで下さい。本機の上に紙や金属等のものを置かないで下さい。ユニットを落下させないように注意し、衝撃や過度の圧力をかけないようにしてください。

Main Features

- 5タイプのワウ/フィルターモード
- オート（タイムベース）、タッチ（ダイナミックレスポンス）の動作モード
- 多彩なコントロール
- フルメタル筐体

- トゥルーバイパススイッチング
- 9Vアダプターで駆動

Pedal layout



- 1. True bypass footswitch:**
エフェクトのON/OFFを切り替えます。
- 2. On/Off Led:**
エフェクトのON/OFFステータスを表示します。
- 3. MODE control:**
フィルターモードの選択と、ミックスおよびフィルターアタックを同時にコントロールします。5つのフィルターモード:
 - LP (ローパス)
 - BP (バンドパス)
 - HP (ハイパス)
 - SP (スタンダード)
 - TALK (トーキングモジュレーター)
- 4. RANGE:**
フィルターの動作範囲を調整します。
- 5. Operation method switch:**
AUTOはタイムベースフィルター、TOUCHはピッキングに合わせて反応するエンベロープフィルターです。
- 6. SPEED / GAIN:**
AUTOモード時のスピードと、TOUCHモード時のレスポンスをコントロールします。

- 7. DC in power jack:**
センターマイナスDC9Vアダプターを接続します。
- 8. Input jack:**
1/4インチモノラルフォン端子の楽器側のケーブルを接続します。
- 9. Output jack:**
1/4インチモノラルフォン端子のアンプ側のケーブルを接続します。

Specification

- Modes :** 5 digital auto filters with 2 methods of operation.
Input : 1/4" mono audio jack. (Impedance: 470k Ohms)
Output : 1/4" mono audio jack (Impedance: 100 Ohms)
Power requirements: AC adapter 9V DC ⊕-⊖, center negative. Highly recommend to use Mooyer Micro Power.
Current Draw: 120mA
Dimensions : 93.5mm(D) x 42mm(W) x 52mm(H)
Weight : 140g
Accessories : Owner's Manual

スペックは予告なく変更される場合があります。